

Follow us



Vmoto

[www.vmoto.com](http://www.vmoto.com)

HAPPINESS IS A JOURNEY

USER MANUAL

**CITI**

# SAFETY INSTRUCTIONS

---

To ensure your safety, please read this manual carefully before riding and make sure you are always following the requirements below:

- 1 Fully understand the information in this manual, include but not limited to the relevant instruction, precautions and warnings.
- 2 Fully understand the operation and contingency measures of CITI smart electric vehicle.
- 3 Be Fully aware of warning labels of CITI smart electric vehicle.
- 4 Don't disassemble vehicle or any parts, if need replacement, please contact local dealer.
- 5 Please keep this manual carefully.



All parameters of this vehicle have been permanently set according to the national standard before leaving factory. The company is not responsible, if the original electrical or circuit has changed and caused excess, such as increase the speed.

# USER INSTRUCTIONS

---

To ensure the safety of you and others, please make sure to observe the following matters:

- 1 Don't lend your vehicle to someone who can't operate it in order to prevent any hurts.
- 2 Please comply with local laws and regulations to drive on the road.
- 3 Do not ride after you take medications which may affect your riding ability, drink alcohol, or when you are unwell.

# USER INSTRUCTIONS

---

- 4** Observe traffic regulations and traffic signs, according to the provisions of laws and regulations to carry man and cargo. Confirm the surrounding road conditions and vehicle condition any time, so as to actively avoid danger.
- 5** In rainy and snowy weather, braking distance will be extended, please slow down, Avoid travelling in bad weather such as storms and typhoons.
- 6** Wear safety equipment, such as helmet, and appropriate protective clothing if necessary, such as gloves and mask.
- 7** To ensure the safety of you and others, please avoid using the high beam under good lighting conditions. Continuous use of the high beam will cause visual obstacles to the opposite vehicles and pedestrians and affect the safe driving.
- 8** Please turn off the power and remove the key immediately after use. Do not allow children to play, so as to avoid loss to your family and property.
- 9** Perform a basic check each time before riding, and regularly go to VMOTO Service Center for maintenance.
- 10** Check before riding. If there is any abnormality, please timely carry out maintenance or seek professional maintenance.
  - a.** Check the status of power circuit, lighting circuit, etc.
  - b.** Check whether the front and rear brakes work normally.
  - c.** Check fixing of handlebars, front and rear wheels.
  - d.** Check tire pressure.



All pictures in this manual are for reference only, please refer to the actual product. The pictures in the manual are based on the VMOTO electric vehicle CITI, please refer to the bikes for details.

The actual product function may differ from the manual content due to technical upgrades, firmware updates or other changes. For the latest function introduction and safe use guide information, please download VMOTO APP, and refer to the embedded electronic manual: or visit the official website of VMOTO: [www.vmoto.com](http://www.vmoto.com)

# QUICK START

---

**-01-**

## Check Accessories Items



× **2**

Remote controls



× **1**

Rear view mirrors



× **1**

User manual



× **2**

Keys



× **1**

Spanner for mirrors




× **1**

Charger

# QUICK START

---

## - 02 - Assemble Parts



# QUICK START

---

## - 03 -

### Install Battery Pack



1 Open the seat


2 Put in the battery pack

3 Plug in the main connector


4 Put down the seat

# QUICK START


## - 04 - Quick Start




- 1 Press "unlock" on remote control.



- 2 Wear helmet.




- 3 Ride on CITI, kick side stand and main stand out.



- 4 Press 'Power' on remote control and press the ignition switch or turn the key to ignition switch 'On' position, power on



- 5 Press 'Parking' button marked 1, unparking CITI, parking symbol off, READY light on. Press the brake handle marked 2.



- 6 Turn accelerator gently, CITI run.

## QUICK START

---

### - 05 -

#### Download APP

**CITI has GPRS function,can connect with your smart phone.  
By APP,you can use smart phone to manage and query your CITI.**

Only IOS and Android are currently available now,please confirm your smart phone operating system in advance.

IOS system:APP only supports Apple ISO 9.0 system and above.

Android system: APP only supports Android 4.4 system and above.

Download and install the VMOTO APP by QR code in this manual .



VMOTO APP

From the date of purchase of the vehicle, you will automatically receive a free two-year central control SIM card data in order to use the VMOTO electric APP function. Please be sure to complete the next year's data recharge before the end of the two-year free period. If the recharge is not overdue, the operator will automatically close the recharge interface, the flow recharge function cannot be restored, and the VMOTO electric vehicle APP cannot be used normally.




# CONTENTS

DESCRIPTION OF COMPONENTS AND PARTS .....	<b>09</b>
OPERATION GUIDE .....	<b>13</b>
RIDING GUIDE .....	<b>18</b>
BATTERY USE INSTRUCTION .....	<b>21</b>
APP INSTRUCTION .....	<b>24</b>
MAINTENANCE .....	<b>26</b>
COMMON PROBLEMS AND TROUBLESHOOTING METHODS .....	<b>28</b>
CHECK LIST .....	<b>33</b>

# DESCRIPTION OF COMPONENTS AND PARTS

## a. Schematic Diagram Of Components And Parts




SIDE VIEW

# DESCRIPTION OF COMPONENTS AND PARTS

---


## a. Schematic Diagram Of Components And Parts



TOP VIEW

# DESCRIPTION OF COMPONENTS AND PARTS

## b. Schematic Diagram Of The Speedometer



### OBD checking error codes

See page 28 FAQ & TROUBLE SHOOTING

### **1** Speed display/fault code

Display the current vehicle speed, when the fault light is on, the fault code will be displayed

### **2** Total mileage/single mileage/remaining mileage

Display the total mileage of the vehicle/single mileage/remaining mileage

### **3** Battery percentage display

Displays the current battery power percentage

**READY** Start lighting  
CPX PRO is **READY** to ride when ready in display

### Cruise indicator light

Cruise indicator light on when cruising

### **R** The light comes on when reversing

Fault prompt accompanied by vehicle fault code display

### vehicle fault code display

Fault prompt accompanied by vehicle fault code display

### Charging indicator flashes

when the battery is less than or equal to 10%

### Turning indicator light

Turning light on and flickering

### Charging light

### **4** Battery display bar

Battery display bar shows the current battery level

### **5** Charging status display

Charging status indicator/low battery status

### **6** Headlight status indication


Headlight on/off status indication

### **7** Data connect condition indication

Data connect condition symbol hint

# DESCRIPTION OF COMPONENTS AND PARTS

## b. Schematic Diagram Of The Speedometer



### TURN ON SWITCHING ADJUSTMENT MODE

#### 1. Press the high beam switch for 3 times

(i.e., the high beam indicator flashes for 3 times) in continuous time such as 4 seconds;

#### 2. At this time, the current display mode

(driving range/ single mileage/ remaining mileage) is flashing, indicating that the motor has entered the adjustment mode;

### DISPLAY SWITCHING (DRIVING RANGE / TRIP RANGE / REVOLVING SPEED)

Turn on switching adjustment mode, and turn on or off the high beam switch to toggle the display mode (driving range / single mileage / remaining mileage) once. Cycle the switching in this way.

### REMOVE SINGLE MILEAGE



If not in trip state; debug to single mileage state (trip), turn on and off the high beam 6 times within 4 seconds, at which time the instrument's single mileage returns to zero.

The meter of the VMOTO electric vehicle may change with version updates and feature upgrades. The actual content of the latest version prevails.

# OPERATION GUIDE

---

## a. Left Switch



### ① High/low beam switch

Up position, high beam on; Down position, low beam on. After turn on the power, turn on and off the high beam 6 times in a row to switch between the kilometers display and the miles display.

### ② Winker switch

Turn to left, left winker on;  
Turn to right, right winker on.


### ③ Horn switch

Press, horn on; release, horn off.

# OPERATION GUIDE

---

## b. Right Switch



### ① Mode switch

CITI is set with 3 modes: 1: ECO mode 2: NORMAL mode 3: SPORT mode.

Position at left, mode 1;

position in the middle, mode 2;

position at right, mode 3.

### ② Parking switch

Press the parking switch up,CITI at parking position,parking indicator (P) light on;press the park switch down display (READY) ,CITI at unparking status.

### ③ Forward reverse switch


Press the switch without letting go, the vehicle enters the state of being ready to reverse, and the vehicle can be reversed by turning the handle; turning the handle to move forward. Release the switch and the vehicle is ready to go.

# OPERATION GUIDE

---

## c. Remote Control

CITI use second generation smart remote control, within 50 meter radius, press the button, can lock or unlock your CITI.





# OPERATION GUIDE


---

## d. Mechanical Key




### 1 Open the seat

Insert the key and turn to the left, the seat can be opened.



### 2 Mechanical key start

After unlocking CITI via remote control, turn the key to "ON" position, power on, turn the key back to "OFF" position, power off.



# OPERATION GUIDE

---

## e. Circuit Protector Switch Operate

As the protection switch for the main power of CITI smart electric vehicle, the circuit protector will automatically disconnect to ensure safety when the vehicle circuit is abnormal or the current caused by short circuit exceeds the set safe value.



**TIPS:** In order to protect your safety, please turn off the circuit protector switch when cleaning, storing the vehicle for a long time, or removing the battery .


# RIDING GUIDE

---

## a. Check List Before Riding

Make sure to check the following items before riding a CITI smart electric vehicle, which will guarantee your safety on the road.


- 1 Whether the handlebar is stable and flexible when turning.
- 2 Whether the switches on the right and left handlebars can work correct.
- 3 Whether the throttle working properly.
- 4 Make sure the tyre pressure is ok. The suggested tire pressure is 200Kpa for front wheel, 225Kpa for rear wheel.
- 5 Check tire surface, make sure no cracks, damage, and foreign matter puncture or attachment.
- 6 Whether the tread depth is sufficient. If the tire is worn to the black shadow mark in the picture, it needs to be replaced.
- 7 Whether any error warning light on the display when power on.
- 8 Whether the battery capacity is sufficient for your trip.
- 9 Whether all lights working properly.
- 10 Whether the horn working properly.
- 11 Whether the mirrors are clean. Adjust them to the proper angle.
- 12 Whether the brake oil is sufficient, whether the brake lever and brake system working properly.




Any exceptions or operational doubts, please contact VMOTO official dealer's service center.

# RIDING GUIDE


## b. Start The Vehicle




- 1** Press “unlock” on remote control.



- 2** Wear helmet.




- 3** Ride on CITI, kick side stand and main stand out.



- 4** Press ‘Power’ on remote control and press the ignition switch or turn the key to ignition switch ‘On’ position, power on



- 5** Press ‘Parking’ button marked 1, unparking CITI, parking symbol off, READY light on. Press the brake handle marked 2.



- 6** Turn accelerator gently, CITI run.

# RIDING GUIDE

---

## **TIPS:**

- ➊ Before riding, make sure side stand and main stand is kicked out, handlebar is unlocked.
- ➋ DON'T press "PARKING" during riding, in case any dangerous due to motor power off and in parking status. DON'T put side stand at standing position, in case any dangerous due to motor power off and in standing status.
- ➌ CITI need to power on under steady standing status. In case any unusual situation, please move the vehicle to side of the road, in case any dangerous, please don't restart the vehicle when it still running or in the middle of the road.

## **c. Riding Precautions**


- ➊ After the riding start, it should accelerate slowly to avoid excessive starting current caused by instantaneous rapid acceleration and increase energy consumption.
- ➋ Under the premise of ensuring safety, try to keep a constant speed on the way you are driving, reduce frequent starts, brake, instant acceleration, etc.
- ➌ Technically permissible maximum laden mass is 280Kg (the rear shelf is 10kg/two-seat version, and the rear trunk is 50Kg/single-seat version).
- ➍ When push vehicle moving forward manually, please press "parking" button, in order to prevent accidents caused by sudden start of the vehicle due to unintentional turning of the throttle. Please turn off the power while parking and remove the key.

# BATTERY USE INSTRUCTION

---

## a. Charging On-board

- ➊ Insert the main charger plug into the charging port of the vehicle.
- ➋ Insert the charger's AC power plug into the socket, and the battery starts charging when the charger indicator turns red.
- ➌ The battery is fully charged if the charger indicator turns from red to green



## Battery level display

**Charging:** red light is on continuously



**Full:** green light on continuously

**Fault:** red and green light flash alternately

# BATTERY USE INSTRUCTION

## b. External Charging

- 1 Open the seat, switch off circuit protector, take out storage cover.
- 2 Disconnect the power plug, take out the battery from vehicle.
- 3 Connect charger with battery, then connect charger with power supply, charger working, red light keeps on.
- 4 If only use one battery, please cover the connector cover with another main connector.



### TIPS:


- Keep battery pack away from water;
- Charging temperature: 0-40°C, discharging temperature: -15°C-45°C;
- Charging battery pack after using, if don't use the vehicle for long time, must take out battery pack from vehicle.
- Forbidden to short circuit positive and negative pole at battery pack input and output position.
- Forbidden to children touch the battery pack and put the battery pack into fire;
- Forbidden to strong impact and press on battery pack;
- Must use official charger, forbidden to use any other charger to charge battery pack;
- Before delivery, battery pack already passed quality checking, forbidden to open the battery pack;

# BATTERY USE INSTRUCTION

---

## c. Storage, Maintenance And Transportation

- ① In case long time no use battery, please charge it till 50%.
- ② Disconnect the battery from vehicle when storing them. Store in dry ventilated place, at least charge 2 hours each 3 months (60V45AH) or 2 hours each 2 months (74V28AH).
- ③ Battery pack and charger need to be stored in clean, dry ventilated place, avoid connect with corrosive material, stay away from power, fire, heat place.
- ④ Battery storage condition: temperature : $25 \pm 3^{\circ}\text{C}$ , humidity  $\leq 65\% \text{RH}$ .
- ⑤ To avoid electric shock, when using single battery, please cover the battery plug with the rubber cover.



If you encounter any problems, please contact the after-sales service department of VMOTO.



# APP INSTRUCTION

---

CITI smart electric vehicle has GPRS communication, GPS positioning and other functions, and can be connected with your smart phone. Through the VMOTO Electric Vehicle APP, you can use your smart phone to manage and query your vehicle.

\*Some functions require the use of wireless networks and positioning functions, please be aware.

The current mainstream mobile phone system versions are iOS and Android operating systems, please confirm the operating system specifications of the smart phone before installation.

## Main functions of VMOTO Electric Vehicle APP (Available subject to different countries)

- ① Vehicle condition diagnosis: when the vehicle is started, a one-key physical examination, real-time understanding of vehicle health status;
- ② Multiple anti-theft: When the vehicle is illegally displaced, the vehicle body will issue an alarm, and the APP will notify the user as soon as possible and track the vehicle location in real time;
- ③ Data recording: Users can learn about vehicle information, remaining power, mileage, riding trajectory and other information through the APP;
- ④ Riding appointments with riders: Through the APP, users can start mobile social interaction, realize communication between people in a new way, and enjoy the fun of online and offline riding.

# APP INSTRUCTION

---

CITI smart electric vehicle has GPRS communications, GPS locate and other functions which can be connect to your smart phone. You can manage your vehicle, query and do other operations by VMOTO APP.



**Download APP**



**Bind APP**

PASTE  
BARCODE

Only iOS and Android are currently available now, please confirm your smart phone operating system in advance.

iOS system:APP only supports Apple iOS 9.0 system and above.

Android system: APP only supports Android 4.4 system and above.

The functions of VMOTO Electric Vehicle APP may vary with version updates, function upgrades and different vehicle types. Please refer to the actual content of the latest version.

# MAINTENANCE

---

Regular maintenance can improve the service life and driving safety of CITI smart electric vehicle. We suggest you follow the following advice to take care of your vehicle.

## **a. Regular Overhaul And Maintenance**

We recommend that after the initial inspection and maintenance of the new vehicle at the VMOTO Authorized Service Center 1,000 km or 3 months after the purchase of the new vehicle (based on the first arrival parameter). It is recommend that you do it every 3,000KM or 6 months (based on the first arrival parameter) for regular inspection and maintenance. VMOTO Authorized Service Center will provide maintenance services for your vehicle (maintenance services may involve fees, please refer to the service center staff or official customer service staff).

### **TIPS:**

The maintenance provided by VMOTO Authorized Service Center is free of charge, which can be did by yourself or at a regular electric vehicle repair shop

## **b. Daily Cleaning And Maintenance**

- **Cleaning:** Please use clean water, neutral detergent, soft cloth and sponge to clean the surface of the vehicle; Do not use metal brush, sandpaper, etc. to wipe the body, so as not to scratch the body and parts. On the surface. After cleaning, wipe the vehicle dry with a soft dry cloth.
- **Storage:** Please park the vehicle in a dry and cool room to reduce sun exposure and rain, in order to avoid corrosion of parts and shorten the service life.

# MAINTENANCE

---

## c. Warning

- 1 Please switch off the circuit protector switch before cleaning.
- 2 Do not use strong pressure water to wash it directly, in order to prevent internal electrical components and lines from intruding or soaking water and causing vehicle mechanical failures or other hidden dangers of accidents.
- 3 In case don't use for long time, please turn off circuit protector switch and disconnect the battery from vehicle; prevent over discharging, please recharge the battery 2 hours each 3 months(60V45AH) or 2 hours each 2 months (74V28AH).
- 4 After long-term storage, please fully charge it before use.

# COMMON PROBLEMS AND TROUBLESHOOTING METHODS

---

## a. FAQ & Troubleshooting

Error	Causes	Solutions
The vehicle has no electricity, and the start button does not shine	<ol style="list-style-type: none"><li>1. Battery is poorly connected</li><li>2. Circuit protector switch is not turned on</li></ol>	<ol style="list-style-type: none"><li>1. Connect the power cable appropriately</li><li>2. Turn on the circuit protector switch</li></ol>
Power on, turning accelerator, motor not run	<ol style="list-style-type: none"><li>1. Low battery power</li><li>2. Side stand is on</li><li>3. At parking mode</li><li>4. Brake lever does not reach the right position</li><li>5. Accelerator error</li><li>6. The controller plug is loose</li><li>7. Controller error</li></ol>	<ol style="list-style-type: none"><li>1. Charge the battery</li><li>2. Kick the side stand out</li><li>3. Press parking button</li><li>4. Place the brake lever at the right position</li><li>5. Change accelerator</li><li>6. Re-plug controller</li><li>7. Change controller</li></ol>
Speed is too slow or mileage is too short	<ol style="list-style-type: none"><li>1. Low battery power</li><li>2. Flat Tyre</li><li>3. Heavily overloaded</li><li>4. Brake pads need to be replaced</li><li>5. Battery aging or normal scrap</li></ol>	<ol style="list-style-type: none"><li>1. Charge the battery</li><li>2. Pump up the tyre, check tyre pressure before riding</li><li>3. Foster a good habit, keep an appropriate load</li><li>4. Change the brake pads and check the brake system before riding</li><li>5. Change the battery</li></ol>
Battery cannot be charged	<ol style="list-style-type: none"><li>1. Poor contact of charger plug</li><li>2. Used wrong charger</li><li>3. Battery aging or normal scrap</li></ol>	<ol style="list-style-type: none"><li>1. Check whether the battery plug is at right position or not</li><li>2. Use VMOTO charger</li><li>3. Change the battery</li></ol>

# COMMON PROBLEMS AND TROUBLESHOOTING METHODS

---

Error	Causes	Solutions
Error 99 on speedometer	Controller communication error	Please contact after sales service or dealer
Error 98 on speedometer	Controller stop working(Possible over current,motor blocking, under voltage,over temperature)	Please stop riding and wait for a while then restart or contact after sales service or dealer
Error 97 on speedometer	Controller power tube error	Please contact after sales service or dealer
Error 96 on speedometer	Controller hall sensor error	Please contact after sales service or dealer
Error 95 on speedometer	Accelerator error	Please check the accelerator plug or contact after sales service or dealer
Error 94 on speedometer	Battery communication error	Please check the battery plug or contact after sales service or dealer
Error 93 on speedometer	Charging, over current error	Please stop charging and check the charger
Error 92 on speedometer	Charging, over voltage error	Please stop charging and check the charger
Error 91 on speedometer	Battery over temperature error	Please stop riding or charging and wait for a while

# COMMON PROBLEMS AND TROUBLESHOOTING METHODS

---

Error	Causes	Solutions
Error 90 on speedometer	Battery discharging over current error	Please stop riding if keep showing and contact after sales service or dealer
Error 89 on speedometer	Battery charging low temperature error	Please move the vehicle to warm indoor place and wait for a while
Error 88 on speedometer	Battery discharging low temperature	Please move the vehicle to warm indoor place and wait for a while
Error 87 on speedometer	Network connection error	Please move the vehicle to open area and wait for a while or contact after sales service or dealer
Error 86 on speedometer	GPS connection error	Please move the vehicle to open area and wait for a while or contact after sales service or dealer

# COMMON PROBLEMS AND TROUBLESHOOTING METHODS

## b. Battery Troubleshooting

Status	Errors	Causes	Solutions
Before using	Battery runs out, unable to activate the vehicle	Battery no power	Please charge the battery
In Operation	In battery low power mode. Battery below 10% ,vehicle power-off	Battery runs out, low-voltage protection	Please charge the battery
In Operation	Display 88 Error code	Battery discharging low temperature	Please move the vehicle to warm indoor place and wait for a while
In Operation	Display 90 error code	Battery discharging over current error	Please stop riding if keep showing and contact after sales service or dealer
In operation	Display 91 error code	Battery over temperature error	Please stop riding or charging and wait for a while
In Operation	Display 94 error code	Battery communication error	Please check the battery plug or contact after sales service or dealer
In Operation	Display power reduce, over night or the next day.	ECU, controller and alarm components take power from battery automatically, normal phenomena.	Normal use
In Operation	Mileage different from the official announced	Official announced mileage is tested under specific circumstances and states. Affected by different road condition, weather, temperature, wind resistance, loading ect.	Any questions, please contact after sales service or dealer



# COMMON PROBLEMS AND TROUBLESHOOTING METHODS

---

Status	Errors	Causes	Solutions
Storage	Press "Start" , no power	The battery is stored too long time, battery runs out	Please charge the battery. If it is not possible to charge, please contact after sales service or dealer
In Charge	Display 89 error code	Charging at low temperature	Please charge the battery in room temperature.
In Charge	Display 92 error code	Charging overage	Stop charging the battery, check the charger
In Charge	The charger gets hot during charging	In the charging process, the internal current of the charger is too high, produce large amount of heat. The metal shell can effectively dissipate heat, which will lead to the high temperature of the shell	Please use normally, charge in dry and ventilated place
Battery water penetration	The battery is not working properly, unable to start the vehicle.	Vehicle in the rain, in the water, wading across deep causing battery flood.	Please stop using, contact after sales service or dealer
Battery box broken	Battery shell broken caused by clash or dorp from high place.	Battery shell broken	Please stop using, contact after sales service or dealer

CHECK LIST	1000 KM 3months	3000KM 6months	6000KM 12months	9000KM 18months	12000 KM 24months	15000 KM 30months	18000 KM 36months	21000 KM 42months	24000KM 48months	Torque (N·m)
Brake fluid	<input type="radio"/>		<input type="radio"/>							
Tire pressure and wear	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>		"FR 200 KPa RR 225 KPa"
Front and rear lining pad wear		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>		
Front and rear brake disc wear			<input type="radio"/>							
Fasten front axle nut and rear wheel bolt	<input type="radio"/>		<input type="radio"/>							59
Fasten the swingarm nut	<input type="radio"/>		<input type="radio"/>							59
The motor and the motor retainer bolt fastening nut	<input type="radio"/>		<input type="radio"/>							80
Fasten Front and rear shock bolt fastening	<input type="radio"/>		<input type="radio"/>		<input checked="" type="radio"/>		<input checked="" type="radio"/>		<input checked="" type="radio"/>	F.Upper 22/ F.Lower 32/R45
Steering column locking nut										74
Fasten front caliper bracket (coated glue thread)	<input type="radio"/>		<input type="radio"/>							26
Fasten front brake disc (coated glue thread)	<input type="radio"/>		<input type="radio"/>							42
Fasten rear caliper bracket (coated glue thread)	<input type="radio"/>		<input type="radio"/>							26
Fasten rear brake disc (coated glue thread)	<input type="radio"/>		<input type="radio"/>							42
Battery	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>		

Note: Check the lithium battery balance by BMS reading and manual measurement.

MAINTENANCE RECORD:

Content:

Date:

MAINTENANCE RECORD:

Content:

Date:

MAINTENANCE RECORD:

Content:

Date:

MAINTENANCE RECORD:

Content:

Date:

MAINTENANCE RECORD:

Content:

Date:

MAINTENANCE RECORD:

Content:

Date: